

at a glance

BOARD FOOT CALCULATOR FOR SPRAY FOAM

A board foot is a 3D measurement of a square foot. Multiply square footage by the depth of the insulation.

1 foot high x 1 foot wide x 1 inch deep

These calculations are influenced by:

- project type
- foam type
- climate

INPUTS FOR CLIMATE ZONE 5

	OPEN CELL	CLOSED CELL
Attic	7 - 12 inches	3 - 6 inches
Basement Ceiling	5 - 10 inches	2 - 3 inches
Basement Wall	N/A	2 - 3 inches
Exterior Wall	3.5 - 5.5 inches	2 - 4 inches

[BACK TO THE ARTICLE](#)

[REQUEST MY FREE QUOTE](#)



**SOUTH
CENTRAL
SERVICES**
INSULATION