

at a glance

HOW TO INSULATE CONCRETE BASEMENT WALLS

OPTIONS FOR CONCRETE WALLS

- Fiberglass batts (budget)
- Faced fiberglass blankets (better)
- Closed cell spray foam (best)

HOW TO INSTALL BATTS

Batt insulation can only be installed in a wood-frame wall constructed in front of the concrete wall.

HOW TO INSTALL BLANKETS

Blankets can be fastened to the concrete with concrete nails.

HOW TO INSTALL SPRAY FOAM

A professional contractor sprays directly against the wall or against a wood-frame wall (1 inch gap between).

[BACK TO THE ARTICLE](#)

[REQUEST MY FREE QUOTE](#)



**SOUTH
CENTRAL
SERVICES**
INSULATION